WORK INSTRUCTION

Document ID: DOC-0001067
Project: PRJ-001
Uploaded on: 2024-04-12
Uploaded by: user140
Export class: EAR99

Assembly of P-101712 at plant PLT04

Part Number: P-101712
Revision: A.1
Plant: PLT04
Station: ST-34
Torque (Nm): 12
Cycle time (s): 68

Step 1: Torque to specification

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Visual check

Step 5: Apply thread locker

Assembly of P-100853 at plant PLT02

Part Number: P-100853
Revision: A.1
Plant: PLT02
Station: ST-17
Torque (Nm): 5
Cycle time (s): 70

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Move to next station

Step 4: Move to next station

Step 5: Visual check

Step 6: Move to next station

Step 7: Move to next station

Step 8: Clean mating surface