WORK INSTRUCTION

Document ID: DOC-0001082
Project: PRJ-020
Uploaded on: 2024-04-23
Uploaded by: user164
Export class: EAR99

Assembly of P-101101 at plant PLT02

Part Number: P-101101
Revision: A.1
Plant: PLT02
Station: ST-23
Torque (Nm): 12
Cycle time (s): 105

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Visual check

Step 5: Torque to specification

Assembly of P-100768 at plant PLT01

Part Number: P-100768
Revision: A.1
Plant: PLT01
Station: ST-65
Torque (Nm): 20
Cycle time (s): 178

Step 1: Inspect incoming part

Step 2: Record result

Step 3: Record result

Step 4: Record result

Step 5: Move to next station