WORK INSTRUCTION

Document ID: DOC-0001123
Project: PRJ-021
Uploaded on: 2024-05-10
Uploaded by: user105
Export class: EAR99

Assembly of P-100467 at plant PLT01

Part Number: P-100467
Revision: B.1
Plant: PLT01
Station: ST-26
Torque (Nm): 20
Cycle time (s): 201

Step 1: Inspect incoming part

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Move to next station