WORK INSTRUCTION

Document ID: DOC-0001133
Project: PRJ-010
Uploaded on: 2024-05-15
Uploaded by: user010
Export class: EAR99

Assembly of P-100932 at plant PLT02

Part Number: P-100932
Revision: A.1
Plant: PLT02
Station: ST-84
Torque (Nm): 8
Cycle time (s): 109

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Torque to specification

Step 6: Inspect incoming part

Step 7: Apply thread locker

Step 8: Record result

Assembly of P-101712 at plant PLT04

Part Number: P-101712
Revision: A.1
Plant: PLT04
Station: ST-78
Torque (Nm): 20
Cycle time (s): 118

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Torque to specification

Step 4: Inspect incoming part

Step 5: Inspect incoming part

Step 6: Clean mating surface

Step 7: Move to next station

Step 8: Clean mating surface