WORK INSTRUCTION

Document ID: DOC-0001172
Project: PRJ-019
Uploaded on: 2024-06-01
Uploaded by: user083
Export class: EAR99

Assembly of P-100262 at plant PLT02

Part Number: P-100262
Revision: A.1
Plant: PLT02
Station: ST-77
Torque (Nm): 5
Cycle time (s): 184

Step 1: Apply thread locker

Step 2: Record result

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Visual check

Assembly of P-101583 at plant PLT03

Part Number: P-101583
Revision: A.1
Plant: PLT03
Station: ST-35
Torque (Nm): 12
Cycle time (s): 66

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Visual check

Step 4: Move to next station

Step 5: Torque to specification

Step 6: Move to next station

Step 7: Torque to specification

Assembly of P-101151 at plant PLT01

Part Number: P-101151
Revision: A.1
Plant: PLT01
Station: ST-56
Torque (Nm): 20
Cycle time (s): 206

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Record result

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Fit fasteners