EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001173
Project: PRJ-011
Uploaded on: 2024-06-01
Uploaded by: user163
Export class: ECCN-3A001

Assembly of P-100759 at plant PLT03

Part Number: P-100759
Revision: A.1
Plant: PLT03
Station: ST-99
Torque (Nm): 5
Cycle time (s): 50

Step 1: Visual check

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Torque to specification

Step 5: Visual check

Step 6: Apply thread locker

Assembly of P-100305 at plant PLT01

Part Number: P-100305
Revision: B.1
Plant: PLT01
Station: ST-23
Torque (Nm): 2.5
Cycle time (s): 268

Step 1: Record result

Step 2: Clean mating surface

Step 3: Record result

Step 4: Apply thread locker

Step 5: Move to next station

Assembly of P-101362 at plant PLT04

Part Number: P-101362
Revision: A.1
Plant: PLT04
Station: ST-49
Torque (Nm): 5
Cycle time (s): 62

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Torque to specification

Step 7: Inspect incoming part