# WORK INSTRUCTION

**Document ID:** DOC-0001315
**Project:** PRJ-007
**Uploaded on:** 2024-07-31
**Uploaded by:** user108
**Export class:** EAR99

## Assembly of P-101894 at plant PLT03

**Part Number:** P-101894
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-97
**Torque (Nm):** 12
**Cycle time (s):** 88

Step 1: Apply thread locker

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Torque to specification

Step 6: Clean mating surface

Step 7: Record result

Step 8: Torque to specification

## Assembly of P-100372 at plant PLT03

**Part Number:** P-100372
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-12
**Torque (Nm):** 2.5
**Cycle time (s):** 44

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Inspect incoming part

Step 5: Clean mating surface