WORK INSTRUCTION

Document ID: DOC-0001354
Project: PRJ-023
Uploaded on: 2024-08-16
Uploaded by: user082
Export class: EAR99

Assembly of P-100844 at plant PLT03

Part Number: P-100844
Revision: A.1
Plant: PLT03
Station: ST-72
Torque (Nm): 8
Cycle time (s): 190

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Clean mating surface

Step 7: Clean mating surface

Assembly of P-101132 at plant PLT04

Part Number: P-101132
Revision: A.1
Plant: PLT04
Station: ST-79
Torque (Nm): 2.5
Cycle time (s): 151

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Apply thread locker

Assembly of P-100930 at plant PLT04

Part Number: P-100930
Revision: A.1
Plant: PLT04
Station: ST-96
Torque (Nm): 2.5
Cycle time (s): 243

Step 1: Clean mating surface

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Fit fasteners