WORK INSTRUCTION

Document ID: DOC-0001372
Project: PRJ-029
Uploaded on: 2024-08-25
Uploaded by: user121
Export class: EAR99

Assembly of P-100561 at plant PLT02

Part Number: P-100561
Revision: A.1
Plant: PLT02
Station: ST-53
Torque (Nm): 2.5
Cycle time (s): 250

Step 1: Visual check

Step 2: Torque to specification

Step 3: Record result

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Apply thread locker

Assembly of P-101707 at plant PLT03

Part Number: P-101707
Revision: A.1
Plant: PLT03
Station: ST-38
Torque (Nm): 8
Cycle time (s): 170

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Apply thread locker

Step 6: Inspect incoming part

Step 7: Fit fasteners

Step 8: Apply thread locker

Assembly of P-100858 at plant PLT01

Part Number: P-100858
Revision: A.1
Plant: PLT01
Station: ST-20
Torque (Nm): 5

Cycle time (s): 253

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Record result

Step 6: Torque to specification

Step 7: Torque to specification

Step 8: Move to next station