WORK INSTRUCTION

Document ID: DOC-0001519
Project: PRJ-006
Uploaded on: 2024-10-27
Uploaded by: user123
Export class: EAR99

Assembly of P-101845 at plant PLT01

Part Number: P-101845
Revision: A.1
Plant: PLT01
Station: ST-22
Torque (Nm): 20
Cycle time (s): 156

Step 1: Torque to specification

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Record result

Step 5: Move to next station

Step 6: Inspect incoming part

Step 7: Clean mating surface

Step 8: Fit fasteners

Assembly of P-101914 at plant PLT02

Part Number: P-101914
Revision: A.1
Plant: PLT02
Station: ST-87
Torque (Nm): 2.5
Cycle time (s): 131

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Record result

Step 5: Record result

Step 6: Inspect incoming part

Step 7: Fit fasteners