# WORK INSTRUCTION

**Document ID:** DOC-0001567
**Project:** PRJ-010
**Uploaded on:** 2024-11-17
**Uploaded by:** user182
**Export class:** EAR99

## Assembly of P-100550 at plant PLT04

**Part Number:** P-100550
**Revision:** A.1
**Plant:** PLT04
**Station:** ST-25
**Torque (Nm):** 2.5
**Cycle time (s):** 145

Step 1: Apply thread locker

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Fit fasteners

## Assembly of P-100280 at plant PLT02

**Part Number:** P-100280
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-50
**Torque (Nm):** 2.5
**Cycle time (s):** 161

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Move to next station

Step 6: Move to next station

Step 7: Fit fasteners

## Assembly of P-101048 at plant PLT02

**Part Number:** P-101048
**Revision:** B.1
**Plant:** PLT02
**Station:** ST-42
**Torque (Nm):** 20
**Cycle time (s):** 178

Step 1: Record result

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Record result