EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001599
Project: PRJ-012
Uploaded on: 2024-12-01
Uploaded by: user196
Export class: ECCN-3A001

Assembly of P-100618 at plant PLT01

Part Number: P-100618
Revision: B.1
Plant: PLT01
Station: ST-81
Torque (Nm): 8
Cycle time (s): 243

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Visual check

Step 4: Move to next station

Step 5: Record result

Step 6: Fit fasteners

Step 7: Fit fasteners

Assembly of P-101691 at plant PLT04

Part Number: P-101691
Revision: A.1
Plant: PLT04
Station: ST-87
Torque (Nm): 2.5
Cycle time (s): 280

Step 1: Inspect incoming part

Step 2: Visual check

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Record result

Step 6: Torque to specification

Step 7: Fit fasteners

Assembly of P-100343 at plant PLT03

Part Number: P-100343
Revision: C.1
Plant: PLT03

Station:	ST-35
Torque (Nm):	2.5
Cycle time (s):	131

Step 1: Torque to specification

Step 2: Visual check

Step 3: Fit fasteners

Step 4: Visual check

Step 5: Inspect incoming part