WORK INSTRUCTION

Document ID: DOC-0001677
Project: PRJ-028
Uploaded on: 2025-01-12
Uploaded by: user182
Export class: EAR99

Assembly of P-100702 at plant PLT01

Part Number: P-100702
Revision: A.1
Plant: PLT01
Station: ST-81
Torque (Nm): 5
Cycle time (s): 142

Step 1: Record result

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Clean mating surface

Step 5: Inspect incoming part

Assembly of P-100337 at plant PLT01

Part Number: P-100337
Revision: A.1
Plant: PLT01
Station: ST-30
Torque (Nm): 20
Cycle time (s): 87

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Record result

Step 5: Inspect incoming part

Step 6: Inspect incoming part