WORK INSTRUCTION

Document ID: DOC-0001732
Project: PRJ-005
Uploaded on: 2025-02-07
Uploaded by: user131
Export class: EAR99

Assembly of P-102645 at plant PLT03

Part Number: P-102645
Revision: A.1
Plant: PLT03
Station: ST-27
Torque (Nm): 5
Cycle time (s): 223

Step 1: Visual check

Step 2: Visual check

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Apply thread locker

Assembly of P-101674 at plant PLT02

Part Number: P-101674
Revision: A.1
Plant: PLT02
Station: ST-36
Torque (Nm): 20
Cycle time (s): 252

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Fit fasteners

Step 5: Inspect incoming part

Step 6: Fit fasteners

Step 7: Move to next station