EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001750
Project: PRJ-029
Uploaded on: 2025-02-16
Uploaded by: user115
Export class: ECCN-3A001

Assembly of P-102254 at plant PLT04

Part Number: P-102254
Revision: A.1
Plant: PLT04
Station: ST-48
Torque (Nm): 20
Cycle time (s): 252

Step 1: Record result

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Apply thread locker

Step 5: Inspect incoming part

Step 6: Torque to specification

Step 7: Record result

Step 8: Move to next station

Assembly of P-100533 at plant PLT04

Part Number: P-100533
Revision: A.1
Plant: PLT04
Station: ST-60
Torque (Nm): 12
Cycle time (s): 226

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Record result

Step 4: Clean mating surface

Step 5: Inspect incoming part

Step 6: Move to next station

Step 7: Fit fasteners