WORK INSTRUCTION

Document ID: DOC-0001784
Project: PRJ-036
Uploaded on: 2025-03-03
Uploaded by: user021
Export class: EAR99

Assembly of P-100871 at plant PLT03

Part Number: P-100871
Revision: B.1
Plant: PLT03
Station: ST-67
Torque (Nm): 20
Cycle time (s): 116

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Visual check

Step 5: Record result

Step 6: Visual check

Step 7: Inspect incoming part

Assembly of P-100972 at plant PLT04

Part Number: P-100972
Revision: A.1
Plant: PLT04
Station: ST-55
Torque (Nm): 12
Cycle time (s): 250

Step 1: Torque to specification

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Inspect incoming part