WORK INSTRUCTION

Document ID: DOC-0001797
Project: PRJ-033
Uploaded on: 2025-03-08
Uploaded by: user032
Export class: EAR99

Assembly of P-101815 at plant PLT03

Part Number: P-101815
Revision: A.1
Plant: PLT03
Station: ST-80
Torque (Nm): 12
Cycle time (s): 62

Step 1: Record result

Step 2: Clean mating surface

Step 3: Record result

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Move to next station

Step 7: Clean mating surface

Step 8: Move to next station

Assembly of P-101395 at plant PLT01

Part Number: P-101395
Revision: A.1
Plant: PLT01
Station: ST-84
Torque (Nm): 2.5
Cycle time (s): 219

Step 1: Inspect incoming part

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Visual check

Step 6: Inspect incoming part

Step 7: Record result

Step 8: Inspect incoming part