WORK INSTRUCTION

Document ID: DOC-0001844
Project: PRJ-016
Uploaded on: 2025-03-28
Uploaded by: user152
Export class: EAR99

Assembly of P-100401 at plant PLT04

Part Number: P-100401
Revision: B.1
Plant: PLT04
Station: ST-88
Torque (Nm): 12
Cycle time (s): 187

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Apply thread locker

Step 5: Inspect incoming part

Step 6: Visual check

Step 7: Move to next station

Assembly of P-102838 at plant PLT03

Part Number: P-102838
Revision: A.1
Plant: PLT03
Station: ST-40
Torque (Nm): 5
Cycle time (s): 164

Step 1: Torque to specification

Step 2: Record result

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Move to next station

Step 6: Visual check

Step 7: Move to next station