WORK INSTRUCTION

Document ID: DOC-0002036
Project: PRJ-040
Uploaded on: 2025-06-27
Uploaded by: user016
Export class: EAR99

Assembly of P-101280 at plant PLT04

Part Number: P-101280
Revision: B.1
Plant: PLT04
Station: ST-57
Torque (Nm): 20
Cycle time (s): 216

Step 1: Visual check

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Inspect incoming part

Assembly of P-100757 at plant PLT02

Part Number: P-100757
Revision: A.1
Plant: PLT02
Station: ST-12
Torque (Nm): 12
Cycle time (s): 173

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Torque to specification

Step 5: Move to next station

Step 6: Record result

Assembly of P-101634 at plant PLT02

Part Number: P-101634
Revision: B.1
Plant: PLT02
Station: ST-70
Torque (Nm): 20
Cycle time (s): 130

Step 1: Torque to specification

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Move to next station

Step 5: Move to next station

Step 6: Apply thread locker

Step 7: Apply thread locker

Step 8: Clean mating surface