WORK INSTRUCTION

Document ID: DOC-0002049
Project: PRJ-007
Uploaded on: 2025-07-03
Uploaded by: user099
Export class: EAR99

Assembly of P-100737 at plant PLT04

Part Number: P-100737
Revision: B.1
Plant: PLT04
Station: ST-12
Torque (Nm): 12
Cycle time (s): 125

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Inspect incoming part

Step 4: Move to next station

Step 5: Clean mating surface

Step 6: Fit fasteners

Step 7: Move to next station

Assembly of P-100604 at plant PLT03

Part Number: P-100604
Revision: A.1
Plant: PLT03
Station: ST-38
Torque (Nm): 12
Cycle time (s): 238

Step 1: Clean mating surface

Step 2: Inspect incoming part

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Inspect incoming part