# WORK INSTRUCTION

**Document ID:** DOC-0002112
**Project:** PRJ-036
**Uploaded on:** 2025-07-29
**Uploaded by:** user061
**Export class:** EAR99

## Assembly of P-100060 at plant PLT01

**Part Number:** P-100060
**Revision:** B.1
**Plant:** PLT01
**Station:** ST-64
**Torque (Nm):** 5
**Cycle time (s):** 202

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Record result

Step 5: Move to next station

Step 6: Record result

Step 7: Torque to specification