WORK INSTRUCTION

Document ID: DOC-0002151
Project: PRJ-026
Uploaded on: 2025-08-25
Uploaded by: user095
Export class: EAR99

Assembly of P-101070 at plant PLT01

Part Number: P-101070
Revision: A.1
Plant: PLT01
Station: ST-74
Torque (Nm): 8
Cycle time (s): 31

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Visual check

Step 6: Record result

Step 7: Inspect incoming part

Step 8: Apply thread locker