WORK INSTRUCTION

Document ID: DOC-0002318
Project: PRJ-026
Uploaded on: 2025-11-13
Uploaded by: user055
Export class: EAR99

Assembly of P-100508 at plant PLT02

Part Number: P-100508
Revision: B.1
Plant: PLT02
Station: ST-90
Torque (Nm): 2.5
Cycle time (s): 125

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Move to next station

Assembly of P-102507 at plant PLT04

Part Number: P-102507
Revision: A.1
Plant: PLT04
Station: ST-95
Torque (Nm): 20
Cycle time (s): 183

Step 1: Record result

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Fit fasteners

Step 5: Fit fasteners