WORK INSTRUCTION

Document ID: DOC-0002334
Project: PRJ-037
Uploaded on: 2025-11-22
Uploaded by: user116
Export class: EAR99

Assembly of P-100271 at plant PLT04

Part Number: P-100271
Revision: A.1
Plant: PLT04
Station: ST-85
Torque (Nm): 20
Cycle time (s): 48

Step 1: Fit fasteners

Step 2: Torque to specification

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Fit fasteners

Step 6: Apply thread locker

Step 7: Move to next station

Assembly of P-100700 at plant PLT04

Part Number: P-100700
Revision: A.1
Plant: PLT04
Station: ST-83
Torque (Nm): 12
Cycle time (s): 191

Step 1: Torque to specification

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Record result

Step 5: Torque to specification

Step 6: Apply thread locker