WORK INSTRUCTION

Document ID: DOC-0002345
Project: PRJ-030
Uploaded on: 2025-11-28
Uploaded by: user128
Export class: EAR99

Assembly of P-100566 at plant PLT03

Part Number: P-100566
Revision: A.1
Plant: PLT03
Station: ST-91
Torque (Nm): 5
Cycle time (s): 196

Step 1: Move to next station

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Inspect incoming part

Step 7: Move to next station

Assembly of P-102409 at plant PLT03

Part Number: P-102409
Revision: A.1
Plant: PLT03
Station: ST-61
Torque (Nm): 12
Cycle time (s): 90

Step 1: Record result

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Clean mating surface

Step 6: Move to next station

Step 7: Apply thread locker

Step 8: Fit fasteners