WORK INSTRUCTION

Document ID: DOC-0002365
Project: PRJ-002
Uploaded on: 2025-12-04
Uploaded by: user083
Export class: EAR99

Assembly of P-101781 at plant PLT01

Part Number: P-101781
Revision: A.1
Plant: PLT01
Station: ST-36
Torque (Nm): 20
Cycle time (s): 155

Step 1: Clean mating surface

Step 2: Record result

Step 3: Record result

Step 4: Fit fasteners

Step 5: Visual check

Step 6: Torque to specification

Assembly of P-103628 at plant PLT03

Part Number: P-103628
Revision: A.1
Plant: PLT03
Station: ST-75
Torque (Nm): 12
Cycle time (s): 69

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Apply thread locker

Step 4: Record result

Step 5: Clean mating surface