WORK INSTRUCTION

Document ID: DOC-0002378
Project: PRJ-031
Uploaded on: 2025-12-12
Uploaded by: user084
Export class: EAR99

Assembly of P-101787 at plant PLT01

Part Number: P-101787
Revision: A.1
Plant: PLT01
Station: ST-37
Torque (Nm): 8
Cycle time (s): 196

Step 1: Record result

Step 2: Record result

Step 3: Clean mating surface

Step 4: Clean mating surface

Step 5: Apply thread locker

Assembly of P-101840 at plant PLT02

Part Number: P-101840
Revision: C.1
Plant: PLT02
Station: ST-87
Torque (Nm): 12
Cycle time (s): 130

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Record result

Step 5: Fit fasteners

Step 6: Inspect incoming part