WORK INSTRUCTION

Document ID: DOC-0002417
Project: PRJ-006
Uploaded on: 2025-12-29
Uploaded by: user081
Export class: EAR99

Assembly of P-100986 at plant PLT03

Part Number: P-100986
Revision: A.1
Plant: PLT03
Station: ST-97
Torque (Nm): 5
Cycle time (s): 102

Step 1: Record result

Step 2: Record result

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Visual check

Assembly of P-102950 at plant PLT03

Part Number: P-102950
Revision: A.1
Plant: PLT03
Station: ST-18
Torque (Nm): 8
Cycle time (s): 215

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Move to next station

Step 5: Apply thread locker

Step 6: Torque to specification

Step 7: Move to next station