EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002480
Project: PRJ-008
Uploaded on: 2026-01-27
Uploaded by: user023
Export class: ECCN-3A001

Assembly of P-103109 at plant PLT02

Part Number: P-103109
Revision: A.1
Plant: PLT02
Station: ST-41
Torque (Nm): 8
Cycle time (s): 241

Step 1: Apply thread locker

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Move to next station

Step 7: Inspect incoming part

Step 8: Inspect incoming part

Assembly of P-103375 at plant PLT04

Part Number: P-103375
Revision: A.1
Plant: PLT04
Station: ST-61
Torque (Nm): 5
Cycle time (s): 121

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Visual check

Step 6: Record result