EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002566
Project: PRJ-036
Uploaded on: 2026-03-06
Uploaded by: user152
Export class: ECCN-3A001

Assembly of P-101599 at plant PLT03

Part Number: P-101599
Revision: A.1
Plant: PLT03
Station: ST-89
Torque (Nm): 2.5
Cycle time (s): 139

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Visual check

Step 4: Move to next station

Step 5: Apply thread locker

Step 6: Torque to specification

Assembly of P-100325 at plant PLT03

Part Number: P-100325
Revision: B.1
Plant: PLT03
Station: ST-12
Torque (Nm): 8
Cycle time (s): 293

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Visual check

Step 6: Inspect incoming part

Step 7: Fit fasteners

Assembly of P-101442 at plant PLT02

Part Number: P-101442
Revision: A.1
Plant: PLT02
Station: ST-16

Torque (Nm):	5
Cycle time (s):	118

Step 1: Torque to specification

Step 2: Clean mating surface

Step 3: Torque to specification

Step 4: Fit fasteners

Step 5: Fit fasteners

Step 6: Fit fasteners

Step 7: Apply thread locker

Step 8: Fit fasteners