WORK INSTRUCTION

Document ID: DOC-0002570
Project: PRJ-036
Uploaded on: 2026-03-07
Uploaded by: user019
Export class: EAR99

Assembly of P-100661 at plant PLT01

Part Number: P-100661
Revision: B.1
Plant: PLT01
Station: ST-69
Torque (Nm): 2.5
Cycle time (s): 202

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Visual check

Step 7: Inspect incoming part

Step 8: Fit fasteners

Assembly of P-100547 at plant PLT01

Part Number: P-100547
Revision: A.1
Plant: PLT01
Station: ST-60
Torque (Nm): 8
Cycle time (s): 256

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Record result

Step 4: Inspect incoming part

Step 5: Visual check

Step 6: Move to next station

Step 7: Apply thread locker

Step 8: Apply thread locker

Assembly of P-103720 at plant PLT01

Part Number: P-103720
Revision: A.1
Plant: PLT01

Station:	ST-54
Torque (Nm):	5
Cycle time (s):	221

Step 1: Move to next station

Step 2: Inspect incoming part

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Visual check

Step 6: Clean mating surface

Step 7: Clean mating surface