WORK INSTRUCTION

Document ID: DOC-0002591
Project: PRJ-016
Uploaded on: 2026-03-16
Uploaded by: user128
Export class: EAR99

Assembly of P-101722 at plant PLT04

Part Number: P-101722
Revision: A.1
Plant: PLT04
Station: ST-39
Torque (Nm): 5
Cycle time (s): 134

Step 1: Fit fasteners

Step 2: Record result

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Move to next station

Step 6: Record result

Step 7: Fit fasteners

Step 8: Record result

Assembly of P-100450 at plant PLT01

Part Number: P-100450
Revision: A.1
Plant: PLT01
Station: ST-16
Torque (Nm): 20
Cycle time (s): 241

Step 1: Apply thread locker

Step 2: Apply thread locker

Step 3: Record result

Step 4: Fit fasteners

Step 5: Torque to specification

Step 6: Move to next station

Step 7: Move to next station

Step 8: Apply thread locker

Assembly of P-102684 at plant PLT02

Part Number: P-102684
Revision: A.1
Plant: PLT02

Station:	ST-51
Torque (Nm):	20
Cycle time (s):	125

Step 1: Clean mating surface

Step 2: Apply thread locker

Step 3: Record result

Step 4: Record result

Step 5: Apply thread locker