WORK INSTRUCTION

Document ID: DOC-0002645
Project: PRJ-028
Uploaded on: 2026-04-11
Uploaded by: user020
Export class: EAR99

Assembly of P-100372 at plant PLT03

Part Number: P-100372
Revision: A.1
Plant: PLT03
Station: ST-77
Torque (Nm): 8
Cycle time (s): 42

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Torque to specification

Step 6: Clean mating surface

Step 7: Fit fasteners

Step 8: Apply thread locker