EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002691
Project: PRJ-015
Uploaded on: 2026-05-03
Uploaded by: user196
Export class: ECCN-3A001

Assembly of P-104199 at plant PLT02

Part Number: P-104199
Revision: A.1
Plant: PLT02
Station: ST-93
Torque (Nm): 12
Cycle time (s): 101

Step 1: Visual check

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Visual check

Step 6: Record result

Step 7: Move to next station

Step 8: Fit fasteners

Assembly of P-102011 at plant PLT02

Part Number: P-102011
Revision: A.1
Plant: PLT02
Station: ST-44
Torque (Nm): 5
Cycle time (s): 214

Step 1: Record result

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Record result

Step 5: Inspect incoming part