WORK INSTRUCTION

Document ID: DOC-0002798
Project: PRJ-004
Uploaded on: 2026-06-29
Uploaded by: user155
Export class: EAR99

Assembly of P-100991 at plant PLT01

Part Number: P-100991
Revision: A.1
Plant: PLT01
Station: ST-19
Torque (Nm): 5
Cycle time (s): 249

Step 1: Record result

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Torque to specification

Step 5: Apply thread locker

Assembly of P-102030 at plant PLT03

Part Number: P-102030
Revision: A.1
Plant: PLT03
Station: ST-83
Torque (Nm): 8
Cycle time (s): 268

Step 1: Apply thread locker

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Fit fasteners