WORK INSTRUCTION

Document ID: DOC-0002851
Project: PRJ-008
Uploaded on: 2026-07-24
Uploaded by: user168
Export class: EAR99

Assembly of P-104419 at plant PLT01

Part Number: P-104419
Revision: A.1
Plant: PLT01
Station: ST-99
Torque (Nm): 2.5
Cycle time (s): 174

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Apply thread locker

Step 7: Move to next station

Assembly of P-101634 at plant PLT02

Part Number: P-101634
Revision: B.1
Plant: PLT02
Station: ST-63
Torque (Nm): 12
Cycle time (s): 40

Step 1: Apply thread locker

Step 2: Record result

Step 3: Visual check

Step 4: Visual check

Step 5: Record result

Step 6: Visual check

Step 7: Record result

Step 8: Move to next station