# WORK INSTRUCTION

**Document ID:** DOC-0002882
**Project:** PRJ-007
**Uploaded on:** 2026-08-03
**Uploaded by:** user160
**Export class:** EAR99

## Assembly of P-100692 at plant PLT04

**Part Number:** P-100692
**Revision:** A.1
**Plant:** PLT04
**Station:** ST-90
**Torque (Nm):** 8
**Cycle time (s):** 74

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Torque to specification

Step 6: Move to next station

## Assembly of P-102243 at plant PLT02

**Part Number:** P-102243
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-48
**Torque (Nm):** 20
**Cycle time (s):** 226

Step 1: Apply thread locker

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Torque to specification

## Assembly of P-102290 at plant PLT02

**Part Number:** P-102290
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-39
**Torque (Nm):** 2.5
**Cycle time (s):** 121

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Record result

Step 4: Clean mating surface

Step 5: Apply thread locker

Step 6: Record result

Step 7: Torque to specification

Step 8: Torque to specification