WORK INSTRUCTION

Document ID: DOC-0002899
Project: PRJ-040
Uploaded on: 2026-08-10
Uploaded by: user085
Export class: EAR99

Assembly of P-101143 at plant PLT04

Part Number: P-101143
Revision: A.1
Plant: PLT04
Station: ST-84
Torque (Nm): 5
Cycle time (s): 110

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Clean mating surface

Step 7: Fit fasteners