# WORK INSTRUCTION

**Document ID:** DOC-0002918
**Project:** PRJ-003
**Uploaded on:** 2026-08-20
**Uploaded by:** user181
**Export class:** EAR99

## Assembly of P-102737 at plant PLT01

**Part Number:** P-102737
**Revision:** A.1
**Plant:** PLT01
**Station:** ST-99
**Torque (Nm):** 12
**Cycle time (s):** 101

Step 1: Torque to specification

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Clean mating surface

Step 5: Inspect incoming part

Step 6: Torque to specification

Step 7: Move to next station

Step 8: Fit fasteners

## Assembly of P-101183 at plant PLT03

**Part Number:** P-101183
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-74
**Torque (Nm):** 5
**Cycle time (s):** 160

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Move to next station

Step 6: Clean mating surface

Step 7: Fit fasteners