WORK INSTRUCTION

Document ID: DOC-0002975
Project: PRJ-019
Uploaded on: 2026-09-24
Uploaded by: user099
Export class: EAR99

Assembly of P-102650 at plant PLT01

Part Number: P-102650
Revision: A.1
Plant: PLT01
Station: ST-28
Torque (Nm): 2.5
Cycle time (s): 236

Step 1: Apply thread locker

Step 2: Record result

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Inspect incoming part

Step 6: Move to next station

Step 7: Inspect incoming part

Step 8: Record result

Assembly of P-102355 at plant PLT04

Part Number: P-102355
Revision: A.1
Plant: PLT04
Station: ST-19
Torque (Nm): 12
Cycle time (s): 124

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Record result

Step 4: Clean mating surface

Step 5: Inspect incoming part

Step 6: Clean mating surface

Step 7: Inspect incoming part