WORK INSTRUCTION

Document ID: DOC-0003009
Project: PRJ-007
Uploaded on: 2026-10-11
Uploaded by: user192
Export class: EAR99

Assembly of P-103107 at plant PLT01

Part Number: P-103107
Revision: A.1
Plant: PLT01
Station: ST-94
Torque (Nm): 2.5
Cycle time (s): 160

Step 1: Torque to specification

Step 2: Fit fasteners

Step 3: Apply thread locker

Step 4: Record result

Step 5: Apply thread locker

Step 6: Apply thread locker

Assembly of P-103692 at plant PLT02

Part Number: P-103692
Revision: A.1
Plant: PLT02
Station: ST-11
Torque (Nm): 20
Cycle time (s): 243

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Record result

Step 4: Torque to specification

Step 5: Inspect incoming part