WORK INSTRUCTION

Document ID: DOC-0001212
Project: PRJ-032
Uploaded on: 2024-06-17
Uploaded by: user011
Export class: EAR99

Assembly of P-101361 at plant PLT03

Part Number: P-101361
Revision: A.1
Plant: PLT03
Station: ST-11
Torque (Nm): 5
Cycle time (s): 89

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Inspect incoming part

Step 5: Apply thread locker

Step 6: Move to next station

Step 7: Fit fasteners

Step 8: Torque to specification

Assembly of P-101102 at plant PLT02

Part Number: P-101102
Revision: A.1
Plant: PLT02
Station: ST-99
Torque (Nm): 8
Cycle time (s): 225

Step 1: Move to next station

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Record result

Step 5: Move to next station

Step 6: Inspect incoming part

Step 7: Apply thread locker

Step 8: Apply thread locker