WORK INSTRUCTION

Document ID: DOC-0001455
Project: PRJ-039
Uploaded on: 2024-09-29
Uploaded by: user029
Export class: EAR99

Assembly of P-100816 at plant PLT03

Part Number: P-100816
Revision: A.1
Plant: PLT03
Station: ST-99
Torque (Nm): 2.5
Cycle time (s): 129

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Record result

Step 5: Fit fasteners