WORK INSTRUCTION

Document ID: DOC-0001497
Project: PRJ-035
Uploaded on: 2024-10-18
Uploaded by: user124
Export class: EAR99

Assembly of P-102237 at plant PLT02

Part Number: P-102237
Revision: A.1
Plant: PLT02
Station: ST-51
Torque (Nm): 12
Cycle time (s): 132

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Apply thread locker

Step 6: Torque to specification

Step 7: Clean mating surface

Step 8: Torque to specification