# WORK INSTRUCTION

**Document ID:** DOC-0001172
**Project:** PRJ-019
**Uploaded on:** 2024-06-01
**Uploaded by:** user083
**Export class:** EAR99

## Assembly of P-100264 at plant PLT04

**Part Number:** P-100264
**Revision:** A.1
**Plant:** PLT04
**Station:** ST-77
**Torque (Nm):** 5
**Cycle time (s):** 184

Step 1: Apply thread locker

Step 2: Record result

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Visual check

## Assembly of P-101624 at plant PLT02

**Part Number:** P-101624
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-35
**Torque (Nm):** 12
**Cycle time (s):** 66

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Visual check

Step 4: Move to next station

Step 5: Torque to specification

Step 6: Move to next station

Step 7: Torque to specification

## Assembly of P-101180 at plant PLT03

**Part Number:** P-101180
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-56
**Torque (Nm):** 20
**Cycle time (s):** 206

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Record result

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Fit fasteners