WORK INSTRUCTION

Document ID:	DOC-0000729
Project:	PRJ-001
Uploaded on:	2023-10-19
Uploaded by:	user051
Export class:	EAR99

Assembly of P-100832 at plant PLT02

Part Number:	P-100832
Revision:	A.1
Plant:	PLT02
Station:	ST-46
Torque (Nm):	20
Cycle time (s):	211

Step 1: Record result

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Apply thread locker

Step 5: Inspect incoming part

Step 6: Fit fasteners

Step 7: Clean mating surface

Step 8: Apply thread locker