WORK INSTRUCTION

Document ID: DOC-0000733
Project: PRJ-018
Uploaded on: 2023-10-21
Uploaded by: user029
Export class: EAR99

Assembly of P-100707 at plant PLT03

Part Number: P-100707
Revision: B.1
Plant: PLT03
Station: ST-34
Torque (Nm): 12
Cycle time (s): 278

Step 1: Fit fasteners

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Torque to specification

Step 6: Apply thread locker

Step 7: Visual check