EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000763
Project: PRJ-022
Uploaded on: 2023-11-06
Uploaded by: user012
Export class: ECCN-3A001

Assembly of P-100637 at plant PLT01

Part Number: P-100637
Revision: A.1
Plant: PLT01
Station: ST-44
Torque (Nm): 8
Cycle time (s): 109

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Inspect incoming part

Step 6: Move to next station

Step 7: Torque to specification

Assembly of P-100761 at plant PLT04

Part Number: P-100761
Revision: A.1
Plant: PLT04
Station: ST-47
Torque (Nm): 12
Cycle time (s): 37

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Move to next station

Step 6: Inspect incoming part

Assembly of P-100273 at plant PLT02

Part Number: P-100273
Revision: A.1
Plant: PLT02
Station: ST-18

Torque (Nm):	12
Cycle time (s):	238

Step 1: Record result

Step 2: Inspect incoming part

Step 3: Fit fasteners

Step 4: Visual check

Step 5: Torque to specification

Step 6: Record result

Step 7: Torque to specification