WORK INSTRUCTION

Document ID: DOC-0002482
Project: PRJ-019
Uploaded on: 2026-01-29
Uploaded by: user027
Export class: EAR99

Assembly of P-101275 at plant PLT02

Part Number: P-101275
Revision: A.1
Plant: PLT02
Station: ST-85
Torque (Nm): 12
Cycle time (s): 73

Step 1: Torque to specification

Step 2: Record result

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Move to next station

Step 6: Apply thread locker

Assembly of P-101521 at plant PLT03

Part Number: P-101521
Revision: A.1
Plant: PLT03
Station: ST-82
Torque (Nm): 8
Cycle time (s): 209

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Visual check

Step 4: Visual check

Step 5: Fit fasteners