WORK INSTRUCTION

Document ID: DOC-0002489
Project: PRJ-010
Uploaded on: 2026-01-31
Uploaded by: user017
Export class: EAR99

Assembly of P-101475 at plant PLT01

Part Number: P-101475
Revision: B.1
Plant: PLT01
Station: ST-73
Torque (Nm): 12
Cycle time (s): 299

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Apply thread locker

Assembly of P-102433 at plant PLT01

Part Number: P-102433
Revision: A.1
Plant: PLT01
Station: ST-69
Torque (Nm): 2.5
Cycle time (s): 86

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Clean mating surface

Step 5: Inspect incoming part